



#1440
Handi-Mate®

HANDI-MATE®

Outboard Motor Extension Handle

Fits virtually all twist-grip outboard motors!

#1441
Handi-Mate®
Swivel

KEY FEATURES

- Lightweight—only 16 ounces (0.45 kg)
- Non-slip comfort grip
- Easy to install and operate
- Tough polycarbonate head simply clamps over existing grip
- Access hole for kill button
- Loosen knob to remove
- Does not affect throttle tension adjustment
- Extends handle from 30–47" (.76–1.19 meters)
- Depress button & align proper hole for desired length; turn locking knob to secure
- Anodized aluminum, stainless steel hardware—no parts to rust or corrode

Special Features of the Handi-Mate® Swivel, the latest model of the popular Handi-Mate® outboard motor extension handle:

- With "Swivel Lock," can be used as a straight steering unit or as a swivel unit while trolling
- To steer with the swivel, simply push or pull on the extension handle; to change to locked position, press a button and pull tube until it latches

ONE-YEAR WARRANTY

We warrant our products to be free of defects in material and workmanship for one year from the date of original purchase. Write for full warranty details.

REPLACEMENT PARTS

Part No.	Description	Price Each
R1440A	Handi-Mate Knob	\$ 2.00
R1440B	Handi-Mate Body	15.00

OPERATING INSTRUCTIONS

For all Handi-Mate Models:

1. Place motor in neutral.
2. Loosen knob and push handle head over throttle grip.
3. Tighten knob to secure head to grip. Be sure to leave room for thumb access to kill button. Do not over tighten.
4. Should excessive torque be required to operate throttle, have your marine dealer adjust throttle tension linkage.
5. Rinse after each use with clean water and wipe dry to help insure years of trouble-free use.
6. Use extra caution when operating the handle the first few times in order to get the feel. Avoid excessive speed.
7. Length can be adjusted by depressing button and aligning with proper hole for desired length.

Caution: Do not try adjusting length while underway.

For Handi-Mate Swivel:

The Handi-Mate with "Swivel Lock" may be used as a straight steering unit or as a swivel unit while trolling.

To steer with the swivel:

Stop the boat. Press the stainless steel button to change from locked position to swivel. Then simply push or pull on the Handi-Mate extension handle while trolling.

To change from swivel to lock position:

Stop the boat. Press the stainless steel button located 2 inches (5 cm) from the clamping body, then push the tube into the body until it latches in the open hole.

CAUTION

Steering with the swivel engaged should be limited to trolling speeds. Do not operate at high speed without first locking into rigid position.

Davis Instruments

3465 Diablo Avenue, Hayward, CA 94545, U.S.A.
Phone (510) 732-9229 • Fax (510) 732-9188
info@davisnet.com

For information about our other fine products,
visit www.davisnet.com