



39

INSTRUMENTS - BEIGE GOLD AND ULTRAWHITE SS SERIES

INSTRUMENT	DIAL RANGE	DESCRIPTION	SENDER	HOLE SIZE mm - in	BEIGE-GOLD PART No.	U-WHITE SS PART No.
Tachometer	6000 RPM	• For all 4, 6 & 8 cylinder inboard & I/O gas engine.	Not required	85 - 3.37	62053 Y	62004 J
	7000 RPM	• Universal for all outboard engines 4, 6, 8, 10, 12 & 20 pole.	Not required	85 - 3.37	62051 U	62003 G
	4000 RPM	• Diesel 5:1, 1:1, 1.5:1, 2:1 mechanical take off	Page 44	85 - 3.37	62054 A	62005 L
	4000 RPM	• Diesel, variable ratio for alternator connection	Not required	85 - 3.37	62054 A	62005 L
Tach-Hourmeter	7000 RPM	• Universal for all outboard engines 4, 6, 8, 10, 12 & 20 pole.	Not required	85 - 3.37	62055 C	62006 N
	4000 RPM	• Diesel 5:1, 1:1, 1.5:1, 2:1 mechanical take off	Page 44	85 - 3.37	62056 E	62007 R
	4000 RPM	• Diesel, variable ratio for alternator connection	Not required	85 - 3.37	62056 E	62007 R
Speedometer	30 Knot 50 Knot 70 Knot	—	Requires pitot tube (Page 44)	85 - 3.37 85 - 3.37 85 - 3.37	62057 G 62058 J 62059 L	62008 T 62009 V 62010 D
Fuel level gauge	E - 1/2 - F	—	Page 44 - 46	53 - 2.07	62063 B	62014 M
Water level gauge	E - 1/2 - F	—	Page 46	53 - 2.07	62067 K	62018 W
Oil pressure gauge	5 bar 10 bar	—	Page 44	53 - 2.07 53 - 2.07	62065 F 62066 H	62016 S 62017 U
Transmission pressure gauge	25 bar	—	Not available	53 - 2.07	62077 N	62052 W
Water temperature gauge	40 - 120 °C	—	Page 44	53 - 2.07	62073 E	62024 R
Voltmeter	10-16 Volt 20-32 Volt	For all 12 Volt electrical system For all 24 Volt electrical system	Not required Not required	53 - 2.07 53 - 2.07	62071 A 62072 C	62022 L 62023 N
Hourmeter	10.000 ore	Elapsed in hour / tenths (12-32 volt)	Not required	53 - 2.07	62064 D	62015 P
Ammeter	60 - 0 - 60	Indicates electrical charge / discharge rate	Not required	53 - 2.07	62060 V	62011 F
Battery charge indicator	E - 1/2 - F	12 Volt, internally illuminated, remote mounted sensor with 20' harness included	Not required	53 - 2.07	62061 X	61012 H
Clock	—	Quartz analog	Not required	53 - 2.07	62062 Z	62013 K
Synchronizer	—	All twin gas & diesel inboard	Not required	85 - 3.37	62074 G	62025 T
Rudder angle indicator	Port-Starboard	Indicates relative position of rudder	Page 44	53 - 2.07	62076 L	62027 X
Trim indicator	Up-Down	• For Mercury and Mariner outboards, Mercruiser, Volvo DP, '96 and newer, Volvo and Yamaha EST sterndrives • For OMC outboards • For Yamaha outboards '97 and newer	Requires sender for outboard and sterndrive engines	53 -2.07 53 -2.07 53 -2.07	62068 M 62069 P 62070 Y	62019 Y 62020 G 62021 J



ELECTRONIC FLUX-GATE COMPASS

- Auto compensation
- Easy to install and to read in all weather conditions
- Unaffected by metal objects in the vicinity of the compass indicator
- Includes: remote mounted sensor with 20' plug in harness, instruction manual and mounting hardware

62078 R – BEIGE GOLD Style Electronic Compass
62079 T – ULTRAWHITE SS Style Electronic Compass