

INSTRUMENT	DIAL RANGE	DESCRIPTION	SENDER	HOLE SIZE mm - in	ULTRA PART No.	ULTRA WHITE PART No.
Tachometer	6000 RPM	• For all 4, 6 & 8 cylinder inboard & I/O gas engine.	Not required	85 - 3.37	60738 G	60691 K
	7000 RPM	• Universal for all outboard engines 4, 6, 8, 10, 12 & 20 pole.	Not required	85 - 3.37	60509 S	60533 T
	4000 RPM	• Diesel 5:1, 1:1, 1.5:1, 2:1 mechanical take off	Page 44	85 - 3.37	60510 J	60534 U
	4000 RPM	• Diesel, variable ratio for alternator connection	Not required	85 - 3.37	60510 J	60534 U
Tach-Hourmeter	7000 RPM	• Universal for all outboard engines 4, 6, 8, 10, 12 & 20 pole.	Not required	85 - 3.37	61766 H	61767 K
	4000 RPM	• Diesel 5:1, 1:1, 1.5:1, 2:1 mechanical take off	Page 44	85 - 3.37	62049 H	62050 S
	4000 RPM	• Diesel, variable ratio for alternator connection	Not required	85 - 3.37	62049 H	62050 S
Speedometer	30 Knot 50 Knot 70 Knot	–	Requires pitot tube (Page 44)	85 - 3.37 85 - 3.37 85 - 3.37	60512 L 60513 M 60514 N	60536 W 60537 X 60538 A
Fuel level gauge	E - 1/2 - F	–	Page 44 - 46	53 - 2.07	60518 T	60542 U
Water level gauge	E - 1/2 - F	–	Page 46	53 - 2.07	60520 L	60544 W
Oil pressure gauge	5 bar 10 bar	–	Page 44	53 - 2.07 53 - 2.07	60521 M 60522 N	60545 X 60546 Y
Transmission pressure gauge	25 bar	–	Not available	53 - 2.07	60523 O	60547 Z
Water temperature gauge	40 - 120 °C	–	Page 44	53 - 2.07	60526 R	60550 U
Voltmeter	10-16 Volt 20-32 Volt	For all 12 Volt electrical system For all 24 Volt electrical system	Not required Not required	53 - 2.07 53 - 2.07	60529 W 60741 Z	60553 X 60742 A
Hourmeter	10.000 ore	Elapsed in hour/tenths, (12-32 volt)	Not required	53 - 2.07	60530 Q	60554 Y
Ammeter	60 - 0 - 60	Indicates electrical charge/discharge rate	Not required	53 - 2.07	60532 S	60540 S
Battery charge indicator	E - 1/2 - F	12 Volt, internally illuminated, remote mounted sensor with 20' harness included	Not required	53 - 2.07	62080 B	62081 D
Clock	–	Quartz analog	Not required	53 - 2.07	60531 R	60539 B
Synchronizer	–	All twin gas & diesel inboard	Not required	85 - 3.37	60517 Q	60541 T
Rudder angle indicator	Port-Starboard	Indicates relative position of rudder	Page 44	53 - 2.07	60699 U	60700 Q
Trim gauge	Up-Down	• Mercury & Mariner outboard, Mercruiser, Volvo DP, '96 & newer, Volvo & Yamaha EST sterndrive. • OMC outboard Johnson & Evinrude. • Yamaha & Evinrude Yamaha outboard '97 & newer.	Requires sender for outboard and sterndrive engines	53 - 2.07	61655 Y	62044 X
				53 - 2.07	62045 Z	62046 B
				53 - 2.07	62047 D	62048 F



ELECTRONIC FLUX-GATE COMPASS

- Auto compensation
- Easy to install and to read in all weather conditions
- Unaffected by metal objects in the vicinity of the compass indicator
- Includes: remote mounted sensor with 20' plug in harness, instruction manual and mounting hardware

61076 N – ULTRA Style Electronic Compass

61077 O – ULTRA WHITE Style Electronic Compass

